



## ROWE TACTICAL BERETTA 1301 STOCK ADAPTER FOR MAGPUL SGA STOCK (MOSSBERG 500/590/ 590A1)

**CHECK FIREARM IS UNLOADED AND SAFE BEFORE CONTINUING!**

**STEP 1:** REMOVE BUTTPAD SCREWS WITH A PHILLIPS SCREWDRIVER, AND SET BUTTPAD ASIDE.



**STEP 2:** USING A 13MM SOCKET REMOVE THE LOCK NUT AND LOCK WASHER FROM FIREARM. THEN SLIDE THE BUTTSTOCK OFF OF THE THREADED ROD.



**STEP 3:** USING A 12MM WRENCH, REMOVE THE OEM THREADED ROD ASSEMBLY FROM THE FIREARM. SOME FORCE AND HEAT MAY BE REQUIRED.



**STEP 4:** APPLY THE VIBRATIE THREAD SOLUTION TO THE THREADS OF THE ROWE TACTICAL PLUNGER ASSEMBLY. SET ASIDE FOR 10 MINUTES TO ALLOW VIBRATITE TO CURE.



**STEP 5:** THREAD THE ROWE TACTICAL PLUNGER ASSEMBLY INTO THE FIREARM RECEIVER, AND TIGHTEN WITH THE PROVIDED 1/4" OPEN END BOX WRENCH.



**STEP 6:** ALIGN ROWE TACTICAL ADAPTER PLATE WITH FIREARM RECEIVER.



**STEP 7:** ALIGN MAGPUL BUTTSTOCK, AND TIGHTEN THE PROVIDED SCREW WITH WASHER TO THE PLUNGER ASSEMBLY, WITH THE PROVIDED ALLEN WRENCH.



**STEP 8:** COMPLETE ASSEMBLY BY SNAPPING IN THE SCREW COVER PLATE.

