



ROWE TACTICAL BERETTA 1301 STOCK ADAPTER FOR MAGPUL SGA STOCK (REMINGTON 870)

CHECK FIREARM IS UNLOADED AND SAFE BEFORE CONTINUING!

STEP 1: REMOVE BUTTPAD SCREWS WITH A PHILLIPS SCREWDRIVER, AND SET BUTTPAD ASIDE.



STEP 2: USING A 13MM SOCKET REMOVE THE LOCK NUT AND LOCK WASHER FROM FIREARM. THEN SLIDE THE BUTTSTOCK OFF OF THE THREADED ROD.



STEP 3: USING A 12MM WRENCH, REMOVE THE OEM THREADED ROD ASSEMBLY FROM THE FIREARM. SOME FORCE AND HEAT MAY BE REQUIRED.



STEP 4: APPLY THE VIBRATIE THREAD SOLUTION TO THE THREADS OF THE ROWE TACTICAL PLUNGER ASSEMBLY. SET ASIDE FOR 10 MINUTES TO ALLOW VIBRATITE TO CURE.



STEP 5: THREAD THE ROWE TACTICAL PLUNGER ASSEMBLY INTO THE FIREARM RECEIVER, AND TIGHTEN WITH THE PROVIDED 1/4" OPEN END BOX WRENCH.



STEP 6: ALIGN ROWE TACTICAL ADAPTER PLATE WITH FIREARM RECEIVER.



STEP 7: ALIGN MAGPUL BUTTSTOCK, AND TIGHTEN THE PROVIDED SCREW TO THE PLUNGER ASSEMBLY, WITH THE PROVIDED ALLEN WRENCH.



STEP 8: COMPLETE ASSEMBLY BY SNAPPING IN THE SCREW COVER PLATE.

